

İşlem Bulaşanları

Vural Gökmen



7. GIDA
MÜHENDİSLİĞİ
KONGRESİ

24 - 26 Kasım 2011
Ankara







‘işlenmiş’

RAFİNE YAĞLAR




Kloropropanol esterleri
Glisidol esterleri



FIRINCILIK ÜRÜNLERİ



Akrilamid



Asparajin

Askorbik asit

Linolenik asit

Gliseritler

ÇEREZ GIDALAR




Akrilamid
Furan

BEBE PÜRELERİ



Furan



İŞLEM BULAŞANLARI

HAM MADDE




ISIL

işlem


$$IN - OUT + GEN = ACC$$

ÜRÜN

Termal Proses - Kara Kutu



Ateş
1 milyon yıl önce
mağara adamı




Ekmek
MÖ 8 000
gıda mühendisi

Ne öğrendik?

Louise Pasteur (1882-1895)

- Kendiliğinden oluş!
- Mikrobiyal bulaşı
 - Termal Yolla Gıda Muhafazası



Gıda Endüstrisine Etkileri

- Modernizasyon
 - Pastörizasyon
 - Sterilizasyon
- Yeni teknolojiler
 - HTST, UHT




konserve



aseptik proses

Isıl İşlemin Temelleri

- Termal direnç
 - En dirençli
 - Termal inaktivasyon
- Isı girişimi
 - Soğuk nokta
 - t/T değişimi, F_0 değeri, letalite, sterilite
- Stumbo (1973)
 - 57 Tablo (geniş T aralığında z-değerleri)




Isıl İşlemin Yan Etkileri

- Besin ögesi kayıpları
 - Vitaminler
 - Amino asitler
 - Lipidler
- m/o inaktivasyonu / besin kaybı
 - D-değeri / C-değeri
 - Fayda / Risk



∴ proses başarısı

Askorbik asit



Web of Knowledge [v.5.4] - Web of Science Citation Report

http://apps.webofknowledge.com/CitationReport.do?product=WOS&search_mode=CitationReport&SID=Z2B3a acrylamide

Journals Science Bank gov.trv Apple HU News Google Translate Google Maps YouTube Wikipedia Popular VG

WEB OF KNOWLEDGESM

DISCOVERY STARTS HERE



Sign In | Marked List (0) | My EndNote Web | My ResearcherID | My Citation Alerts | My Saved Searches | Log Out | Help

Web of Science

Additional Resources

Search | Author Finder | Cited Reference Search | Advanced Search | Search History

Web of ScienceSM


<< Back to previous results list

Citation Report Topic=(ASCORBIC* FOOD)


Timespan=1970-2011. Databases=SCI-EXPANDED, SSCI, A&HCI, CPCI-S, CPCI-SSH.

This report reflects citations to source items indexed within Web of Science. Perform a Cited Reference Search to include citations to items not indexed within Web of Science.

Published Items in Each Year



Citations in Each Year



Results found: 2850

Sum of the Times Cited [?]: 50451

Sum of Times Cited without self-citations [?]: 46055

Citing Articles[?]: 36982


[View Citing Articles](#)

[View without self-citations](#)

Average Citations per Item [?]: 17.70


h-index [?]: 94

Louis Camille Maillard (1878-1936)




Maillard LC, 1912
Hodge JE, 1953



Maillard Reaksiyonu



Akrilamid Oluşum Mekanizması




t/T - Akrlamid



Açar, Ö.Ç., Gökmen, V. (2009) Investigation of acrylamide formation on bakery products using a crust-like model, *Molecular Nutrition and Food Research*, 53, 1521-1525

Proses hedefleme
< 200 ng/g Akrilamid



$$Risk = t \cdot 10^{\left(\frac{T-200}{z}\right)}$$

SICAK NOKTA

$$Letalite = t \cdot 10^{\left(\frac{T-121.1}{z}\right)}$$

SOĞUK NOKTA



Proses hedefleme
12 log azalma (*C. botulinum*)



A new approach to evaluate the risk arising from acrylamide formation in cookies during baking: Total risk calculation

Özge Çetinkaya Açar, Vural Gökmen*

Food Engineering Department, Hacettepe University, 06800 Beytepe, Ankara, Turkey

ARTICLE INFO

Article history:

Received 22 February 2010
Received in revised form 28 April 2010
Accepted 14 May 2010
Available online 24 May 2010

Keywords:

Acrylamide
Cookie
Baking
Risk evaluation

ABSTRACT

From a food engineering point of view, a viable approach in evaluating the risk related to acrylamide formation in heated foods is still lacking. In this study, thermal process calculation procedure used to evaluate safe levels of microbial inactivation by means of time-temperature history of the product during processing was adapted to evaluate the risk associated with acrylamide formation in cookies during baking. The rate constants were determined in model cookies during baking at different temperatures. For a risk threshold value of 200 ppb of acrylamide, thermal formation times were calculated as 6.29, 0.20 and 0.03 min for 150, 200 and 250 °C, respectively. The *F* and *z* values were determined as 0.20 min and 30 °C, respectively, for acrylamide formation in cookies during baking. Calculated total risk values compared well with experimentally measured acrylamide concentrations of cookies baked under different conditions confirming the success of risk evaluation procedure.


© 2010 Elsevier Ltd. All rights reserved.

1. Introduction

The discovery of acrylamide in heated foods by Swedish researchers in April 2002 (Tareke et al., 2002) has been considered as an important food-related crisis by international authorities, since acrylamide is a neurotoxin and has been classified as proba-

temperatures well above the ambient boiling point of water in pressurized steam retorts (Simpson et al., 2003). Thermal process calculations, in which process times at specified temperatures are calculated, are performed in order to achieve safe levels of microbial inactivation (lethality) and these calculations should be carefully carried out to ensure public health safety. The first proce-

Akrylamid



Web of Knowledge [v.5.4] - Web of Science Citation Report

http://apps.webofknowledge.com/CitationReport.do?product=WOS&search_mode=CitationReport&SID=Z2B3a

acrylamide

WEB OF KNOWLEDGESM

DISCOVERY STARTS HERE

THOMSON REUTERS

[Sign In](#) | [Marked List \(0\)](#) | [My EndNote Web](#) | [My ResearcherID](#) | [My Citation Alerts](#) | [My Saved Searches](#) | [Log Out](#) | [Help](#)

Web of Science

Additional Resources

[Search](#) | [Author Finder](#) | [Cited Reference Search](#) | [Advanced Search](#) | [Search History](#)

Web of ScienceSM


[<< Back to previous results list](#)

Citation Report Topic=(ACRYLAMIDE* FOOD)


Timespan=1970-2011. Databases=SCI-EXPANDED, SSCI, A&HCI, CPCI-S, CPCI-SSH.

This report reflects citations to source items indexed within Web of Science. Perform a Cited Reference Search to include citations to items not indexed within Web of Science.

Published Items in Each Year



Citations in Each Year



Results found: 880

Sum of the Times Cited [?]: 12467

Sum of Times Cited without self-citations [?]: 4908

Citing Articles[?]: 3280

[View Citing Articles](#)

[View without self-citations](#)

Average Citations per Item [?]: 14.17

h-index [?]: 50



PROMETHEUS



PROCESSING CONTAMINANTS

Processing contaminants are food-born molecules that are formed during the heat process of foods when temperature reaches high values. Such molecules exhibit in vitro toxic activity, so that mitigation is needed to prevent any possible negative long-term impact on the consumer. PROMETHEUS will investigate the impact of processing on the outbreak of six main neo-formed contaminants: 1 acrylamide, 2 furan, 3 HMF [5-hydroxymethylfurfural], 4 3-MCPD esters, 5 glycidol esters and 6 N -(carboxymethyl) lysine (CML). Four different food models will be studied: infant formula, biscuits, baby food puree and canned fish.

FOUR MITIGATION STRATEGIES

VACUUM BAKING

Applying vacuum during baking contributes to reduce the temperature compared to conventional baking systems. In the project, this technology will be used on biscuits to reduce the possible formation of processing contaminants such as acrylamide and HMF.

CONTACT [Vural Gökmen, Hacettepe University \(Turkey\)](#)

HIGH HYDROSTATIC PRESSURE

Using high pressure is another possibility to control the formation of Maillard reaction products. With this technology, the products are introduced in their final package into a vessel and subjected to a high level of isostatic pressure (between 300-600 MPa), transmitted by water. Here again, high pressure allows decreasing the sterilization temperature. The treatment will be tested on baby food puree and canned fish.

CONTACT [Henry Jaeger, Technische Universität Berlin \(Germany\)](#)

OHMIC HEATING

Ohmic heating technology is an innovative thermal technology based on High Temperature Short Time treatment: unlike conventional treatments, ohmic processing heats products internally by passing an electric current through the product, rather than relying on heat transfer from a heated vessel. Ohmic heating will be applied to infant formulas and baby food puree.

CONTACT [Elisabeth Payeux, CTCPA \(France\)](#)

INGREDIENT MICROENCAPSULATION

Protecting by microencapsulation the nutrients involved in the formation of processing contaminants is a promising technique to mitigate contamination. The project will investigate the possibility to microencapsulate Vitamin C, iron, polyunsaturated fatty acids (PUFA) and sodium chloride in biscuits and infant formula.

CONTACT [Samira El Mafadi Jian, Capsulae \(France\)](#)
and [Vincenzo Fogliano, University of Napoli \(Italy\)](#)

	Liquid infant formulas	Biscuits cookies	Fruit and vegetable baby food purees	Processed Fish & Processed vegetables
Vacuum baking				
High pressure treatment				
Ohmic heating				
Microencapsulation				

THREE INNOVATIVE MONITORING STRATEGIES

FRONT FACE FLUORESCENCE ANALYSIS TO MONITOR FOOD PROCESS CONTAMINANTS

Fluorescence spectroscopy is a sensitive analytical technique particularly suitable for monitoring the impact of processing and storage on food quality parameters, especially on heat-derived undesirable compounds: the method is rapid, non-destructive and simple to apply. In the framework of Prometheus, an online sensor will be developed to control the heat charge absorbed by food products and monitor the main heat-influenced quality indicators. Software allowing prediction in real time will also be elaborated for an on-line follow-up of processing contaminant formation.

CONTACT [Inès Birtouez, Spectralys Innovation \(France\)](#)

AMBIENT MASS SPECTROMETRY

Direct analysis in real time (DART) is a novel ambient desorption ionization technique. It enables quantification of processing contaminants and their precursors very specifically and with high sensitivity, and it has the possibility to induce thermal changes in the matrix: changes of temperature can be monitored directly on line. In the project, DART mass spectrometry will be used to investigate the reaction intermediates leading to processing contaminant precursors.

CONTACT [Jana Hajšlova, VSCHT \(Czech Republic\)](#)

COMPUTER VISION BASED IMAGE ANALYSIS

Computer vision-based image analysis can be used as a tool to predict the browning phenomenon associated to food severe heat treatment. This rapid and non-destructive technique will be used to monitor browning of biscuits during baking as well as formation of acrylamide that is strongly correlated with browning.

CONTACT [Vural Gökmen, Hacettepe University \(Turkey\)](#)

MODELLING

The data collected in the project will be analysed, and empirical as well as mechanical models will be developed for a better understanding of the reactions mechanisms leading to the formation of processing contaminants and quantification of the kinetic parameters. Such modelling will make it possible to identify optimal processing parameters and formulation to mitigate process contaminants.

CONTACT [Ine van der Fels-Klerx, RIKILT \(The Netherlands\)](#)





ulusal GIDA TEKNOLOJİ PLATFORMU

yaşam için gıda



Türkiye Gıda ve İçecek Sanayii
Dernekleri Federasyonu



Türkiye Et, Süt, Gıda Sanayicileri
ve Üreticileri Birliği



Meyve Suyu Üreticileri
Derneği



Anadolu Efes Biracılık ve Malt
Sanayii A.Ş.



Eti Gıda San. Tic. A.Ş.



Pinar Süt Mamülleri San. A.Ş.
Pinar Entegre Et ve Un San. A.Ş.

YILDIZ HOLDING

Yıldız Holding



altıparmak

Altıparmak Gıda San. Tic. Koll.
Şti.

ZADE

Helvacızade A.Ş.



Hacettepe Üniversitesi
Teknoloji Transfer Merkezi



Ankara
Üniversitesi



Ege
Üniversitesi



Hacettepe
Üniversitesi



Gaziantep
Üniversitesi



Orta Doğu Teknik
Üniversitesi

1 Ağustos 2011